



# Owner's Manual ADDENDUM



The location and color of the Heater Thermal Cut-Off has changed since the publication of this manual. The Heater reset button is now located towards the front of the heater on the left side. The button which is recessed into the heater body is black (see illustration), and a label indicating it's location is above it. Please disregard any reference in the Owner's Manual to the location and color of the Heater Thermal Cut-Off.

PN 61979 A (1/03)

# Owner's Manual ADDENDUM



The location and color of the Heater Thermal Cut-Off has changed since the publication of this manual. The Heater reset button is now located towards the front of the heater on the left side. The button which is recessed into the heater body is black (see illustration), and a label indicating it's location is above it. Please disregard any reference in the Owner's Manual to the location and color of the Heater Thermal Cut-Off.

PN 61979 A (1/03)